

588 12/15/92 This is a # 22
CONTROLLED DOCUMENT
EG&G - ROCKY FLATS PLANT
ENVIRONMENTAL MANAGEMENT

ROCKY FLATS PLANT
EMD OPERATING
PROCEDURES MANUAL

Manual No.: 5-21000-OPS-GT
Procedure No.: Table of Contents, Rev 30
Page: 1 of 3
Effective Date: 12/14/92
Organization: Environmental Management

THIS IS ONE VOLUME OF A SIX VOLUME SET
WHICH INCLUDES:

VOLUME I: FIELD OPERATIONS (FO)
VOLUME II: GROUNDWATER (GW)
VOLUME III: GEOTECHNICAL (GT)
VOLUME IV: SURFACE WATER (SW)
VOLUME V: ECOLOGY (EE)
VOLUME VI: AIR (AP)

TABLE OF CONTENTS
FOR VOLUME III: GEOTECHNICAL

<u>Procedure No.</u>	<u>Title</u>	<u>Rev. No.</u>	<u>Effective Date</u>
GT.01	Logging Alluvial and Bedrock Material	2	05/12/92
DCN 92.01	Specialized Logging Form	2	11/13/92
GT.02	Drilling and Sampling Using Hollow Stem Auger Techniques	2	05/12/92
DCN 92.01	Superseded by DCN 92.03	2	07/27/92
DCN 92.02	Superseded by DCN 92.03	2	07/27/92
DCN 92.03	Addition of the Drum Characterization	2	07/27/92
DCN 92.04	Prevention of Down Hole Contamination	2	08/26/92
DCN 92.05	Field Modification	2	12/04/92
GT.03	Isolating Bedrock from Alluvium with Grouted Surface Casing	2	05/12/92
DCN 92.03	Expired	2	09/03/92
GT.04	Rotary Drilling and Rock Coring	2	05/12/92

DOCUMENT CLASSIFICATION REVIEW WAIVER
PER R.B. HOFFMAN, CLASSIFICATION OFFICE
JUNE 11, 1991

ADMIN RECORD

A-SW-001112

**ROCKY FLATS PLANT
EMD OPERATING
PROCEDURES MANUAL**

**Manual No.: 5-21000-OPS-GT
Procedure No.: Table of Contents, Rev 30
Page: 2 of 3
Effective Date: 12/14/92
Organization: Environmental Management**

<u>Procedure No.</u>	<u>Title</u>	<u>Rev. No.</u>	<u>Effective Date</u>
GT.05	Plugging and Abandonment of Boreholes	2	05/12/92
DCN 92.01	Field Modification	2	12/09/92
GT.06	Monitoring Wells and Piezometer Installation	2	05/12/92
DCN 92.05	Schematic Diagram Land Fill Methane Wells	2	06/04/92
DCN 92.06	Field Modification	2	11/12/92
GT.07	Logging and Sampling of Test Pits and Trenches	2	05/12/92
GT.08	Surface Soil Sampling	2	05/12/92
DCN 92.01	Clarification of Soil Sampling	2	09/03/92
DCN 92.02	Consistency Change	2	10/12/92
GT.09	Soil Gas Sampling and Field Analysis	2	05/12/92
GT.10	Borehole Clearing	2	05/12/92
GT.11	Plugging and Abandonment of Wells	2	05/12/92
GT.15	Geophysical Borehole Logging	2	05/12/92
GT.17	Land Surveying	2	05/12/92
GT.18	Surface Geophysical Surveys	2	05/12/92
DCN 92.01	Surface Magnetic Surveys Procedure	2	09/30/92
DCN 92.02	Modification to Stacking Requirements	2	10/15/92
DCN 92.03	Modification to Method of Taking Readings	2	10/15/92
GT.19	Field Gas Chromatographs	2	05/12/92

**ROCKY FLATS PLANT
EMD OPERATING
PROCEDURES MANUAL**

**Manual No.: 5-21000-OPS-GT
Procedure No.: Table of Contents, Rev 30
Page: 3 of 3
Effective Date: 12/14/92
Organization: Environmental Management**

<u>Procedure No.</u>	<u>Title</u>	<u>Rev. No.</u>	<u>Effective Date</u>
GT.20	Procedures for Soil Interstitial Water Sampling and Sampler Installation	2	05/12/92
GT.21	Cone Penetrometer Testing	1	05/12/92
GT.24	Approval Process for Construction Activities on or Near Individual Hazardous Substance Sites (IHSSs)	0	05/12/92

EDB 12/15/92 This is a #22

**CONTROLLED DOCUMENT ENVIRONMENTAL MANAGEMENT
EG&G - ROCKY FLATS PLANT DOCUMENT CHANGE NOTICE (DCN)
ENVIRONMENTAL MANAGEMENT**

This is a RED Stamp

Procedure Number 5-21000-OPS-GT.5, Rev. 2

Title Plugging and Abandonment of Boreholes	Date 12-9-92	DCN Number 5-21000-OPS-92.01
Expires <u>12/9/93 MCB</u> Procedure Revision Required <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No		
Scope Limitation <u>none</u>		

EDB

Item Number	Page	Step or Paragraph	Changes (Use DCN CONTINUATION SHEET for Additional Space)
1	6 of 8	paragraph 1 line 7	Add after the sentence "The tremie pipe will then be removed from the hole." : For borings less than 10 feet deep, where groundwater was not encountered, plugging will consist of mixing grout according to the manufacturer's recommendations either manually or with a mechanical mixer. The grout will then be poured into the boring.

Justification (Reason for Change – Provide Numbers To Reference Corresponding Items Above)

For shallow holes, a tremie pipe is not necessary to ensure complete plugging of the borehole. In addition, small quantities of grout can be readily and thoroughly mixed by hand.

**DOCUMENT CLASSIFICATION REVIEW WAIVER
PER R.B. HOFFMAN, CLASSIFICATION OFFICE
JUNE 11, 1991**

Concurrence	Organization	Req	Date	Concurrence	Organization	Req	Date
<i>[Signature]</i>	QAPM	X	12/9/92	<i>[Signature]</i>	User	X	12/9/92
<i>[Signature]</i>	EOM	X	12/8/92	<i>[Signature]</i>	User	X	12/9/92
				<i>[Signature]</i>	User	X	12/9/92
Approval of Responsible Manager <i>[Signature]</i>		Date	12-8-92	Is Posting Req'd? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	If Yes, By What Date?	Date Posted	